

Desktop Leathers

Hand dyed Hides and Skivers

2 Priory Lodge, Church Road, Hatfield Peverel, Chelmsford, Essex, CM3 2LE

Tel: +44(0)1245 382134

charles.cope@talk21.com

Leather and Skiver Inlay fitting instructions

1. Remove old leather top by soaking with lukewarm water.
2. Scrape and clean exposed wood surface.
3. Fill all cracks and dents with woof filler.
4. Sand down lightly to provide a smooth flat surface.
5. Use Solvite wallpaper paste and apply a thin film of paste to exposed wood surface, enabling you to adjust leather until correct position is found.
6. Lay leather firmly into edges, and trim off excess with a "Stanley" knife.
7. Allow to dry (2/3 hours).
8. Fill in any gaps around the edge with dark wax polish.
9. Polish dry with a clean dry cloth.

Tips

- Knifing round the edge of the top before starting to lay the leather will give a score mark that will help guide the knife later.
- A blunt knife, or sharpened piece of wood is useful for getting the leather right into the edges.
- Make sure that the wooden top is clean and flat, and that there are no pieces of grit or wood chips etc. on the back of the leather as any lumps will show through.